

H-210 ULTRASONIC WASHING SHAMPOO

Usage Areas:

It gives excellent results in the cleaning of aerospace, jewelry industry, optical industry, automotive industry, electroplating processes, brass (yellow) materials.

Specifications:

- It can be used safely on all metals.
- It is very effective in cleaning polish, polishing residues and oils.
- It is water based and non-flammable.
- It shows very fast performance in ultrasonic washing baths.

Usage Rates:

Add 1-2 lt to 100 liters of water.

Usage:

Water is filled in the ultrasonic washing machine. After the water is heated (70°C), first the appliance is operated without shampoo for 2-3 minutes. Then, the required amount of shampoo is added while the device is running.

